

Fitting Instructions KCA387

WHITELINE
PO Box 5666, Minto, NSW, 2566 Australia
Ph: 61 2 9603 0111 Fax: 61 2 9820 2500
E-mail: admin@whiteline.com.au
A.B.N. 68 073 002 034

Flat out

Code: Z279

Application: Mitsubishi Lancer Evolution VII VIII

KCA387 - Steering Precision Kit is designed to improve the steering feel, precision and response while reducing understeer and increasing front grip specifically on turn-in. This is achieved through the use of low compliance replacement mounting bushes and special spacers to alter steering geometry.

Contents: Each kit contains:

- 1 x Power steering mounting bush - passenger side
- 4 x Power steering mounting bush - driver side
- 2 x Power steering mounting bush tubes - driver side
- 1 x Alloy spacer plate - passenger side
- 2 x High tensile steel spacer discs - driver side

Fitting: Please read the complete instructions before commencing work.

1. Whiteline recommend that all work be carried out by a qualified technician. Fitting is best done with the vehicle on a hoist.
2. It is recommended to measure wheel alignment settings prior to fitment.
3. Remove original steering mount bushes. This will require removing or partially removing of cross-member, exhaust and other related parts to gain access to steering rack mounts.
4. Fit new KCA387 steering rack mounting bushes.
5. During assembly of the steering rack onto the cross-member, fit spacer plate on the passenger side, and 2 spacer discs on the drivers side, between bushes and the cross-member.
6. Reassemble steering rack, cross-member, exhaust and all other related parts.
7. Test drive the vehicle, and check tension on all fasteners.
8. Measure wheel alignment, and adjust as required.
9. Check & re-tension all fittings again after 100 kms but no more than 200 kms.



Warning: Please drive carefully while you accustom yourself to the changed vehicle behaviour.