

Fitting Instructions KSR205

WHITELINE
AUTOMOTIVE *Flat out*
PO Box 5666, Minto, NSW, 2566 Australia
Ph: 61 2 9603 0111 Fax: 61 2 9820 2500
E-mail: admin@whiteline.com.au
A.B.N. 68 073 002 034

Code: Z290

Application:

Subaru Impreza MY05 WRX & STi.
Refer catalogue for exact listing.



KSR205 is a performance steering rack mounting kit.

Whiteline's unique design with carefully chosen polyurethane hardness offers improved steering control and response while at the same time reducing steering thump and shudder.

Stock design and dimensions have been totally revised to minimise lateral compliance with minimal change to NVH. Whiteline KSR205 is designed to be more subtle at high frequency's yet firmer in control situations.



Contents:

Each kit contains;

- ✓ 4 x driver-side half bushes
- ✓ 1 x passenger-side bush
- ✓ 2 x driver-side metal tubes
- ✓ 1 x grease sachet

Fitting:

Please read the complete fitting instructions before commencing work. Whiteline recommends that all work be carried out by a qualified technician.

1. Raise front of the vehicle and support on safety chassis stands.
2. Remove any undercarriage guards and braces to enable access to steering rack mounts.
3. Undo and remove steering rack mounting bolts and brackets.
4. Remove original bushes.
5. Assemble all KSR205 bushes in place. Grease supplied can be used to lubricate bushes to ease the installation.
6. Assemble all steering rack mounting bolts. Tighten driver's side first, then passenger's side bolts to manufacturer's recommended torque settings.
7. Refit any undercarriage guards and braces, and lower the vehicle.
8. Check & re-tension all fittings again after 100kms but no more than 200kms.



Warning: Please drive carefully while you accustom yourself to the changed vehicle behaviour.